


PRODUCT INTRODUCTION

TIPS: If the product is missing, damaged, deformed, please contact us for a free replacement, sorry for the trouble.




Bulb* 2

INSTALLATION INSTRUCTIONS

1. If you have no experience in replacing a bulb, please search on YouTube and check the installation video before installing it. We

- The head of the HID bulb is made of glass, please take care to prevent breakage during installation and operation;
- The head of the HID bulb is an optical device. It is recommended to wear gloves during the installation to avoid smearing the bulb surface and affecting its optical effect;
- After the bulb is installed correctly, there will still be a certain space for turning. No need to worry about it, it's normal;
- Please don't look directly at the HID bulb turned on to prevent your eyes from being hurt by the light;
- Due to the limited operating space of some models, you may need to remove the assembly or remove some equipment;
- There are a positive and a negative on the plug, please note the direction during installation.



Step 5: Connect the new HID bulb to the plug, and then install it into the assembly, pay attention to align the positioning slot when installing; If assembly space is limited, you can install the bulb before connecting the plug;

Step 6: Fasten the bulb in place by turning it clockwise;

Step 7: Close the back cover and close the Engine Hood, then you are done.

2. Models: D2S/D4S



Step 1: Parking your car, and make sure the headlights are turned off for more than half an hour to avoid burns;

Step 2: Open the hood, locate the bulb that needs to be replaced, and remove the back cover (the ballast and the cover are one piece for most vehicle models), which you may need to rotate or pull out;

PRODUCT PARAMETERS

Voltage	D1S/D2S:85V D3S/D4S:42V
Color Temp	4500K/6000K/8000K
Ambient Temp	-40 C -120 C
Power	35W

FAQ

1. Q: Fail to match with your car?

A: You may buy the wrong bulb model, please check and replace it.

2. Q: Fail to switch on after installation or switch off automatically in few minutes after on?

A: It may be caused by the mismatch between the bulb and ballast. The output characteristics of ballast may vary for different vehicle models, so there will be a certain probability that the voltage output waveform is unmatched, causing the bulb can't be switched on normally.

We suggest you search keywords "HID+ Model you bought + headlight bulb".



2. Notes and Instructions before Installation

- Please check whether the original bulb model matches with the model you purchased before installation, as D1S, D3S, D2S and D4S are highly similar, only the voltage is different, and 85% of the vehicle models have both HID and Halogen versions. If you buy the wrong one, please contact us for a free replacement; The head of the HID bulb is made of glass, please take care to prevent breakage during installation and operation;



INSTALLATION STEPS

1. Models: D1S/D3S/D8S



Step 1: Park the vehicle and make sure the headlights are turned off for more than half an hour, in case you get burned;

Step 2: Open the hood, locate the bulb that needs to be replaced, and remove the dust cover (the ballast and the back cover are one piece for most vehicle models), which you may need to rotate or pull out;



Step 3: Locate the HID bulb, and turn counterclockwise or loosen the spring to remove the bulb;



Step 4: Unplug it;



Step 3: Locate the HID bulb, and unplug the ballast. You may need to turn the plug counterclockwise and pull it out;



Step 4: Open the spring fastener, and take out the bulb;



Step 5: Install the new HID bulb and into the assembly and secure it with a spring fastener;



Step 6: Connect bulb and plug and rotate clockwise to fix it;

Step 7: Close the back cover and close the Engine Hood, then you are done.

3. Q: Fail to switch both headlights on?

A: Maybe one bulb is not installed properly, please check it, and then try to switch the left and right bulb for a further test.

4. Q: Poor Light Pattern?

A: Maybe the bulb is not installed in place, causing the light point to not be in focus, reinstall it.

5. Q: The plug is wrong connected?

A: There are a positive and a negative on the plug, please make sure which side is positive, which is negative. If the PIN is deformed, correct it with a tool and reinstall it.

CUSTOMER SERVICE TEAM

+86 15013298898
support@dmex.cc

If you have any questions, please contact our customer service team

Made In China